## **Hopkins County Schools**

## **Technology Department**

## Nortel Phone Set Programming -

To program your phone you will use the Nortel Feature Key as shown here:



## **Programming Buttons** -

You have the following three options for programming buttons: *External Numbers, Internal Extensions, or System Feature.* 

External Numbers: (Feature Key, \*, 1)

- 1. Press Feature Key
- 2. Press \* 1
- 3. Press the button you wish to store the number
- 4. Enter the number exactly as you would dial it, including the 9 before the number
- 5. Screen shows Programmed if done correctly

Internal Extension: (Feature Key, \*, 2)

- 1. Press Feature Key
- 2. Press \* 2
- 3. Press the button you wish to store the number
- 4. Enter the extension number
- 5. Screen shows Programmed if done correctly

System Feature: (Feature Key, \*, 3)

- 1. Press Feature Key
- 2. Press \* 3
- 3. Press the button you wish to program the feature
- 4. Press the Feature Key (you will see an F on the screen)
- 5. Enter the feature code for the feature you desire
- 6. Verify on the screen that it was Programmed