

Nortel Feature Code Quick Reference

All the Feature without the * can be programmed to a button using Feature * 3

FEATURE	* 0	BUTTON INQUIRY (FOR BUTTONS THAT AREN'T MARKED)
FEATURE	* 1	PROGRAMMING OUTSIDE AUTODIAL ONTO A MEMORY BUTTON
FEATURE	* 2	PROGRAMMING INSIDE AUTODIAL ONTO A MEMORY BUTTON
FEATURE	* 3	PROGRAMMING A FEATURE TO A MEMORY BUTTON
FEATURE	* 4	PROGRAMMING PERSONAL SPEED DIAL
FEATURE	* 7	CONTRAST ADJUSTMENT (ON THE LCD DISPLAY)
FEATURE	* 80	RING VOLUME ADJUSTMENT
FEATURE	0	SPEED DIAL
FEATURE	3	CONFERENCE
FEATURE	4	CALL FORWARD TO ANOTHER EXTENSION (TO CANCEL PRESS FEATURE # 4)
FEATURE	5	LAST NUMBER REDIAL
FEATURE	60	PAGE GENERAL
FEATURE	61	PAGE TO INTERNAL PAGE ZONE
FEATURE	62	PAGE EXTERNAL
FEATURE	63	PAGE TO A PAGE ZONE AND EXTERNAL PAGE
FEATURE	66	VOICE CALL (TO PAGE 1 EXTENSION)
FEATURE	69	PRIORITY CALL
FEATURE	74	CALL PARK
FEATURE	75	CALL PICKUP
FEATURE	79	EXCLUSIVE HOLD
FEATURE	85	DO NOT DISTURB (TO CANCEL PRESS FEATURE # 85)
FEATURE	86	BACKGROUND MUSIC (TO CANCEL PRESS FEATURE # 86)
FEATURE	87	NIGHT SERVICE (TO CANCEL PRESS FEATURE # 87)

Norstar Voice Mail Feature Codes

FEATURE	980	TO LEAVE A MESSAGE IN ANOTHER MAIL BOX
FEATURE	981	TO OPEN YOUR MAIL BOX (DEFAULT PASSWORD 0 0 0 0)
FEATURE	986	TO TRANSFER A CALL TO ANOTHER MAIL BOX